

---

---

# Instruction Sheet - *Planar Antenna*

---

---

**Model : ET-PP16V**

- Step1:** For directional  
**Step2:** Easy Installation  
**Step3:** Excellent coverage



## Electrical Specifications

Name	ET-PP16V
Frequency range	2.4 ~ 2.4835GHz
Polarization	Linear (V or H)
Antenna Gain	16.0dBi
VSWR	≤ 1.5
Cross-Polarization	20dB
Beam-Width	35 ° x 17.5 °
Impedance	50 Ω
Temperature	-40 ~ +80
Relative Humidity	0 to 95% RH

## Mechanical specification

Wind load	120 Km/h
Size (W x H x D mm)	190.4 x 368.4 x 17
Termination	N-type Female

# Antenna Patterns

